# **PT** Platform Scales





PT industrial scales offer durability and quality construction for a variety of different applications. The PT features a large, steel base with a diamond plate surface, adjustable leveling feet and cable. Optional ramps facilitate loading and unloading heavy objects. The platforms are available with or without indicators. Adam offers a range of indicators including the GK, GC, AE 403, AE 503 and AE 504.

## Quality construction with a diamond-plate surface for ultimate durability and performance





## **Features**

- Rugged construction stands up to industrial use
- Diamond-plate surface for added grip
- Optional ramps facilitate loading and unloading
- Can be used with any Adam indicators
- Approximately five-meter/15-foot shielded cable



## **Applications**

- Weighing
- Parts counting
- Checkweighing
- Dynamic / animal weighing

### **Compatible Indicators**



AE 403 Indicator



AE 503 Indicator



**GK Indicator** 



AE 504 Indicator



#### **GC Indicator**

#### About ADAM:

For the past 50 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

## **PT** Platform Scales



## **Product Details**

Model	PT 110	PT 310-5	PT 310-10	PT 112	PT 312-5	PT 312-10	PT 115	PT 315-5	PT 315-10	PT 112M	PT 312-5M	
Capacity	2500lb / 1000kg	5000lb / 3000kg	10000lb / 4500kg	2500lb / 1000kg	5000lb / 3000kg	10000lb / 4500kg	2500lb / 1000kg	5000lb / 3000kg	10000lb / 4500kg	2500lb / 1000kg	5000lb / 3000kg	
Readability	0.5lb / 0.2kg	11b / 0.5kg	21b / 1kg	0.5lb / 0.2kg	1lb / 0.5kg	2lb / 1kg	0.5lb / 0.2kg	1lb / 0.5kg	21b / 1kg	0.5lb / 0.2kg	1lb / 0.5kg	
Excitation Voltage	5 - 10 VAC / DC											
Loadcells	4											
Pan Size	39.4'	39.4"x39.4" / 1000x1000mm			47.2"x47.2" / 1200x1200mm			59.1"x59.1" / 1500x1500mm			47.2"x47.2" / 1200x1200mm	
Operating Temperature		-10° to 40°C / 14° to 104°F										
Housing		Mild steel base										
Cable Length	10' / 3M											
Overall Dim. (WxDxH)	39.4"x39.4"x4.3" / 1000x1000x110mm			47.2"x47.2"x4.3" / 1200x1200x110mm			59.1"x59.1"x4.3" / 1500x1500x110mm			47.2"x47.2"x4.3" / 1200x1200x110mm		
Net Weight		136.6lb / 62kg			174.1lb / 79kg			244.6lb / 111kg			174.1lb / 79kg	
Approvals		N/A						NTEP / Measurement Canada				

#### **Accessories**

Item Number	Description
700100199	Mild Steel Ramp - PT 10R (1000mm wide)
700100200	Mild Steel Ramp - PT 12R (1200mm wide)
700100201	Mild Steel Ramp - PT 15R (1500mm wide)

## **Key Accessories**



#### Mild Steel Ramp

Compatible with several Adam indicators, the PT is designed to weigh pallets, crates and large containers. PT contains an innovative X frame beneath the platform, which reinforces and strengthens the platform for improved support.

Supplied by

Adam Equipment follows a policy of continuous improvement and reserves the right to change specification and pricing without notice. Adam Equipment's standard terms and conditions of sale apply. Errors and omissions excepted.